



Ferri Equipment Set-up Times

Nicola Simoni April 2017



FERRI SET UP TIMES		
MODEL OF MOWER	WHAT NEEDS TO BE DONE TO INSTALL	TIME TO INSTALL
T250A	REMOVE UNIT FROM SKID AND REMOUNT LOWER HITCH ARMS INTO POSITION FOR MOUNTING ON TRACTOR. MOUNT UNIT TO TRACTOR AND INSTALL HYDRAULIC PUMP ONTO PTO OUTPUT SHAFT AND FASTEN TO TRACTOR SO PUMP DOES NOT SPIN. RUN CONTROLS UP INTO CAB AND MAKE MOUNT FOR THEM.	2.5 HOURS
T320A	REMOVE UNIT FROM SKID AND REMOUNT LOWER HITCH ARMS INTO POSITION FOR MOUNTING ON TRACTOR. MOUNT UNIT TO TRACTOR THEN CUT AND INSTALL PTO. RUN CONTROLS UP INTO CAB AND MAKE MOUNT FOR THEM.	2 HOURS



FERRI SET UP TIMES		
MODEL OF MOWER	WHAT NEEDS TO BE DONE TO INSTALL.	TIME TO INSTALL
T380D / T430D	REMOVE UNIT FROM SKID AND REMOUNT LOWER HITCH ARMS INTO POSITION FOR MOUNTING ON TRACTOR. MOUNT UNIT TO TRACTOR THEN CUT AND INSTALL PTO. RUN CONTROLS UP INTO CAB AND MAKE MOUNT FOR THEM.	2 HOURS
T460	REMOVE UNIT FROM SKID AND REMOUNT LOWER HITCH ARMS INTO POSITION FOR MOUNTING ON TRACTOR. MOUNT UNIT TO TRACTOR THEN CUT AND INSTALL PTO. RUN CONTROLS UP INTO CAB AND MAKE MOUNT FOR THEM.	2 HOURS



MODEL OF MOWER	WHAT NEEDS TO BE DONE TO INSTALL	TIME TO INSTALL
TM46 FARM	REMOVE UNIT FROM SKID AND REMOUNT LOWER HITCH ARMS INTO POSITION FOR MOUNTING ON TRACTOR. MOUNT UNIT TO TRACTOR THEN CUT AND INSTALL PTO. RUN CONTROLS UP INTO CAB AND MAKE MOUNT FOR THEM.	2 HOURS
TP51 FARM	REMOVE UNIT FROM SKID AND MOUNT UNIT TO TRACTOR THEN CUT AND INSTALL PTO. RUN CONTROLS UP INTO CAB AND MAKE MOUNT FOR THEM.	2 HOURS



MODEL OF MOWER	WHAT NEEDS TO BE DONE TO INSTALL	TIME TO INSTALL
TP61 FARM	REMOVE UNIT FROM SKID AND	4-6 HOURS DEPENDING ON SHOP
	INSTALL BOOM TO FRAME AND MAIN	
	CYLINDER.	
	MOUNT UNIT TO TRACTOR THEN CUT AND	
	INSTALL PTO.	
	RUN CONTROLS UP INTO CAB AND MAKE	
MOUNT FOR THEM.		
INSTALL HEAD ONTO BOOM AND MOUNT		
HYDRAULIC MOTOR TO HEAD.		
TXV 50 / 60	REMOVE UNIT FROM SKID AND	4-6 HOURS DEPENDING ON SHOP
	INSTALL BOOM TO FRAME AND MAIN	
	CYLINDER.	
	MOUNT UNIT TO TRACTOR THEN CUT AND	
	INSTALL PTO.	
	RUN CONTROLS UP INTO CAB AND MAKE	
MOUNT FOR THEM.		
INSTALL HEAD ONTO BOOM AND MOUNT		
HYDRAULIC MOTOR TO HEAD.		
TXV 50 / 60	REAR AXLE RIGID FITTING SYSTEM INSTALLATION (AS AN OPTION)	4-6 HOURS DEPENDING ON SHOP



FERRI SET UP TIMES		
MODEL OF MOWER	WHAT NEEDS TO BE DONE TO INSTALL	TIME TO INSTALL
OFFSET MOWERS ZME, ZMTE, ZLE, ZTE, ZHE, ZMLE	REMOVE UNIT FROM SKID OR CRATE INSTALL OFSET ARMS AND THREE POINT LOOP. INSTALL UNIT ONTO TRACTOR AND PLUG IN HYDRAULICS. INSTALL PTO AND CUT IF NEEDED.	2-3 HOURS DEPENDING ON HOW UNIT IS PACKAGED
INLINE MOWERS ME, MT	REMOVE UNIT FROM PALLET OR CRATE. INSTALL THREE POINT LOOP. INSTALL UNIT TO TRACTOR. CUT AND INSTALL PTO IF NEEDED.	1 HOUR
ALL TIMES ON THESE SHEETS ARE APROXIMATE, THEY WILL VARY FROM SHOP TO SHOP		



Ferri srl

Via Govoni, 30

44034 Tamara (Ferrara) Italy

Tel. +39 0532 866866

Fax +39 0532 866851

info@ferrisrl.it