


PUMP JP-190 ASSEMBLY



B-117

PUMP JP-190 ASSEMBLY

Continuation

Item	CODE	DESCRIPTION	Qty.	Item	CODE	DESCRIPTION	Qty.
00	694315	Pump JP-190 assembly	1				
01	213736	Plug 1/2" BSP	1				
02	210146	O-ring OR1-117	1				
03	1159487	Identification plate "Engraved"	1				
04	109587	Round head rivet	4				
05	663153	Hex. bolt 5/16" - 18 UNC x 3/4"	18				
06	519736	Lock washer M8	18				
07	322834	Packing 132 x 262 x 1.59	1				
08	520775	Drain plug 1/4" BSP	1				
09	325290	O-ring OR1-112	1				
10	322776	Pump cover	1				
11	038778	Connecting rod assembly	3				
12	240838	Crankshaft	1				
13	325506	Bearing 6310	2				
14	323170	Retainer 01920	2				
15	322610	Bearing flange	2				
16	322883	Packing 110 x 145 x 0.4	2				
17	322909	Connecting rod shaft	3				
18	322933	Guide with rode	3				
19	322842	Scraper ring	3				
20	120071	O-ring ORI - 015	3				
21	585604	Piston cup base	3				
22	581363	Piston cup	6				
23	585588	Piston cup spacer	3				
24	585596	Piston cup fastener	3				
25	585612	Hex. nut 1/2" UNF (stainless)	3				
26	585638	Locking screw 1/2" UNF x 15 (stainless)	3				
27	322669	Pump body	1				
28	012724	O-ring ORI-119	1				
29	328542	Plug w 3/4" BSP	1				
30	916775	Snap ring for hole w 40	3				
31	323188	Retainer 72	3				
32	322867	Packing	6				
33	322826	Sleeve guide	3				
34	322925	Sleeve (alumina)	3				
35	322875	Seal washer	3				
36	587378	Valve for pump w 24 - model "D"	6				
37	044487	Valves cover	1				
38	429258	Screw 1/2" - 13 UNC x 3" - stainless steel	8				
39	908582	Lock washer 1/2"	8				
40	427948	Plug w 1.1/2" BSP	2				
41	916734	Hex. nut 5/8" - 11 UNC	4				
42	764142	Lock washer M16	4				
43	322891	Stud bolt 5/8" - 11 UNC x 240 - stainless steel	4				
44	322735	Pump head	1				
45	328799	Valves cover (suction)	1				
46	959957	Sticker: "Keep oil on level"	1				
47	692491	Repair kit VIII	1				
	824201	Lubricating oil - Texaco	1				