



Parts List			
ITEM	QTY	PART NUMBER	DESCRIPTION
10	2	LA-BOQF10 04	BOQF10 Lock Pin
11	2	LA-BOQF10 003	Spring Pin
12	2	LA-BOQF10 002	BOQF10 Lock Spring Retainer Bushing
14	1	LA-BOQF10 13	Joiner Shaft
15	2	LA-BOQF10 15	BOQF10 Lock Pin Spring
17	1	LP-100148	Left Adapter Handle
19	1	LP-100149	Elbow Right Adapter Handle
20	2	LA-SB1022	1/2" Lock Nut
21	2	LA-BOQF10 19	BOQF10 Handle Pivot Spring Washer
22	4	11-1026	5/8" Lock Nut
28	1	LA-BOQF10 005	BOQF10 Hydraulic Right Cyl Mount Assembly
29	1	LA-BOQF10 008	BOQF10 Hydraulic Left Cyl Mount Assembly
30	1	LA-CYL28BOQF10	2" x 8" Cylinder For BOQF10 Hydraulic
31	2	11-1535	3/8" x 2 Roll Pin
34	2	LA-SB1025	5/16" Lock Nut
35	2	LA-SB1026	5/16" x 2 1/4" Bolt