


RPW
RPW 20

AXLE



PI-76159

AXLE**RPW
RPW 20**

<u>REF. NO.</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	24083	Axle
2	24076	Axle Bearing Casting w/zerk
3	24056	Axle Bearing Clamp
4	24079	Bearing Shim, thin
4	24132	Bearing Shim, thick
5	*41232	Spindle, 1 3/4" x 12-1/8" long
6	*26121	Seal, grease kit
7	*11378	Inside Bearing Cone (LM48548)
8	*10345	Outside Bearing Cone(LM67048)
9	*30405	Hub Casting with cups and grease zerk
--	11379	Inside bearing cup (LM48510)
--	10344	Outside bearing cup (LM67010)
10	*16094	Washer, 2" O.D. x 7/8" I.D. flat
11	*88340	Castle Nut, 7/8"
12	*88301	Cotter Pin, 5/32" x 1 1/4" long
13	11381	Dust Cap
14	10498	Wheel Rim, 15" x 8" wide, 6 bolt
15	*88142	Wheel Bolt, 1/2"
16	88600	Bolt, 3/4" - 10 x 6 1/2" long (Grade 5)
17	88531	Bolt, 3/8" - 16 x 3" long
18	88130	Lock washer, 3/4"
19	88362	Lock washer, 3/8"
20	88110	Nut, 3/4" (non lock)
21	88103	Nut, 3/8" (non lock)
22	88143	Grease Zerk, 1/4"
23	41233	1 3/4" spindle and hub assembly (consists of all parts marked by an asterisk)